














Product Type:	<b>Slide Bar</b>
Product Code:	<b>E087072</b>
Product Name:	<b>Flexi Round</b>
Description:	Saliscendi con rosoni quadri regolabile in altezza <i>Slide Bar with square rosettes adjustable in height</i>
Dimensions:	L1000 mm
Material:	Brass
Note:	regolabile in altezza
Notes:	<i>adjustable in height</i>

Functions:	<div></div> <div></div>
Finishes:	<div> Chrome <b>CR</b></div> <div> Nickel Brushed <b>NB</b></div> <div><div>Painted</div><div> Matt Black <b>MB</b></div><div> Matt White <b>WM</b></div></div> <div><div>PVD Polished</div><div> Gold <b>GO</b></div><div> DeepBlack <b>DB</b></div></div> <div><div>PVD Brushed</div><div> High Brass <b>HB</b></div><div> Copper <b>CO</b></div><div> Gun Metal <b>GM</b></div><div> Absolute Black <b>AB</b></div></div>

DIMENSIONS



## PRODUCT CARE

To avoid damages to the purchased equipment, please observe the following recommendations for use:

- Clean the plumbing before connecting the device.
- Periodically clean the water blade to avoid any limestone deposits that could compromise the good functioning.

Advice: The installation of a filter and water-softener system improves and extends the life of the devices and of the plant itself.

### CLEANING OF METAL PARTS:

For an easy cleaning of the metal parts of the product, simply use a soft cloth moistened in water and soap or an anti-limestone detergent.

To avoid spots caused by calcium in water, we advise drying with a cloth after each use.

Advice: Please use only natural soap-based detergents avoiding those with alcohol, hydrochloric acid or phosphoric acid, bleach, chlorine etc. and those containing abrasive powders.

---

## PACKING



10 pcs