

Product Type: **Slide Bar set**
 Product Code: **E144051 | E144052 | E144053 | E144054**
 Product Name: **Deep without water outlet**

Dimensions: L900 mm
 Material: Brass

Note: **saliscendi:** E087049 Deep without water outlet
doccia: disponibili diverse soluzioni*

Notes: **flessibile:** C084021
slidebar: E087049 Deep without water outlet
hand shower: available different solutions*
flex: C084021

Functions:  1 Way |  Rain

Finishes: 
 Chrome
CR

Hand Shower options:



E144051 (KIT CODE):
 E082051 Emotion Ø100
 multi-function chrome
 diffuser



E144052 (KIT CODE):
 E082027 Emotion Ø100
 monojet chrome diffuser




E144053 (KIT CODE):
 E082073 Emotion Ø130
 multi-function white
 diffuser



E144054 (KIT CODE):
 E082043 Emotion Ø130
 monojet chrome diffuser

DIMENSIONS



PRODUCT CARE

To avoid damages to the purchased equipment, please observe the following recommendations for use:

- Clean the plumbing before connecting the device.
- Periodically clean the water blade to avoid any limestone deposits that could compromise the good functioning.

Advice: The installation of a filter and water-softener system improves and extends the life of the devices and of the plant itself.

CLEANING OF METAL PARTS:

For an easy cleaning of the metal parts of the product, simply use a soft cloth moistened in water and soap or an anti-limestone detergent.

To avoid spots caused by calcium in water, we advise drying with a cloth after each use.

Advice: Please use only natural soap-based detergents avoiding those with alcohol, hydrochloric acid or phosphoric acid, bleach, chlorine etc. and those containing abrasive powders.

PACKING



1 pcs
